


ULTRASONIC AROMA DIFFUSER BEWIT FRIEND




User manual

Product description

The aroma diffuser is designed to use the best of both oriental culture and the latest knowledge and technology of western science. The device uses ultrasound to break down essential oil and water into a mist of microparticles, releasing active ingredients and anions into the air.

Ultrasonic technology does not heat the essential oil and preserves all its positive therapeutic effects.



- 01. Mist outlet
- 02. Cover
- 03. Inner cover
- 04. Color changing light bar
- 05. Base
- 06. Function button
- 07. Inlet
- 08. DC jack
- 09. USB plug
- 10. Air outlet
- 11. Ceramic disc
- 12. Water tank (100 ml)
- 13. Max water level line (100 ml)
- 14. Water spout

Use



Read before use:

1. Place the diffuser on a flat, stable surface, away from the edge.
2. Remove the outer cover and then remove the inner cover
3. Fill the reservoir with mineral water (bottled water or tap water); do not exceed the maximum water level - 100 ml (indicated by the word MAX in red letters).
4. Then add a few drops of water soluble fragrance and essential oil (4-6 drops) to the water tank.
5. Replace the inner cover & the outer cover on the diffuser.
6. Plug the USB cable into the DC Jack at the back of the diffuser & Plug the adaptor into the power supply.

WARNING: Use DC 5V/1A adapters only.

Cleaning

Always disconnect the product before cleaning it.



Descaling

Unplug the diffuser from the power source completely. Empty any water inside the recipient. Fill up the reservoir with vinegar/descaling solution. Do not dilute the vinegar/descaling solution with water.

If you use vinegar, let it rest in the reservoir for at least 30 minutes. To obtain the best results, leave it overnight.

If you use a descaling solution, respect the period indicated in the instructions supplied with this solution.

Safety instructions

- This appliance may be used by children over 8 years of age and by persons with reduced physical, sensory or mental abilities or with insufficient experience or knowledge, provided they are supervised or have been given instructions on the safe use of the appliance.

- Children must not use the appliance as a toy.
- Cleaning and maintenance should not be carried out by children when left unsupervised.
- If the appliance is left unsupervised and before assembly, disassembly, filling or cleaning, always disconnect it from the power supply.
- This appliance is intended for domestic use only in accordance with the instructions in this manual.
- Do not use the appliance for any purpose other than that for which it was designed.
- For information on filling, use, cleaning and descaling, please refer to the relevant sections of this manual.
- Clean the tank after each use.
- Keep essential oils out of the reach of children to avoid the risk of poisoning and burns.
- The device may only be used with the supplied cable.
- Do not remove the cover or cover the diffuser when the unit is in use.
- For optimum use, use mineral water (bottled water or tap water). Check that you have not exceeded the maximum water level (100 ml).
- Always pour water into the reservoir before adding essential oils or fragrance (4 to 6 drops).
- The manufacturer is not responsible for any damage caused by improper use of the product.
- Never use a non-standard power adapter to charge the product.

Warranty

This product was rigorously tested before leaving the manufacturer. During the legal warranty period from the date of purchase, the customer may request a free repair or replacement due to defects caused by normal use. If necessary, please contact the seller of the product. Failures due to accidents, improper use or maintenance are not covered by the warranty.



BEWIT FRANCHISE s.r.o.
Michalská 2030,
710 00 Ostrava
Czechia
Tel.: (+420) 731 739 539
Email: info@bewit.cz
www.BEWIT.love