


# AROMA DIFFUSER WITH TWO JETS

## BEWIT DUAL STRONG

### User manual




Model DUAL STRONG

# PRODUCT DESCRIPTION

Aroma diffuser with an elegant design and two jets.

This aroma diffuser can perfectly disperse the pure essential oil, releasing a pleasant scent with the help of two-media spraying technology.

Therefore, you can enjoy a pleasant aromatherapy experience with warm (yellow) - cool (blue) ambient light.



## Components:


- |   |                                |   |
|---|--------------------------------|---|
| 1. Aluminum alloy box                     | 5. Essential oil bottle        | 9. Ambient light C                        |
| 2. Upper control panel<br>Control buttons | 6. Spray Core (Atomising Core) | 10. Charging indicator light              |
| 3. Vaporiser cover                        | 7. Essential oil suction tube  | 11. Charging cable type (see accessories) |
|   | 8. Type-C charging port        |   |

## Accessories:

User Manual 1, Atomizer Core 2, Essential Oil Suction Tube 2, Type C Charging Cable 1


# INSTRUCTIONS

- Carefully remove the spray cap and unscrew the essential oil bottle.
- Pour the essential oil into the bottle.  
Each of the bottles (left and right) can be filled with a different type of essential oil.  
(Note:  
Do not fill the essential oils above the line of the bottle's screw thread).
- Screw the essential oil bottle into the atomizer cap and place it in the diffuser.





## Functions of buttons on the operation panel

- Power button - On and off button Press the button to turn the diffuser on, press the button to turn the diffuser off.
- 'T' - Button for controlling the operating time of the diffuser



- ON - The diffuser is in operation  
 1H - The diffuser operates for 1 hour and then turns off automatically  
 2H - The diffuser operates for 2 hours and then turns off automatically  
 4H - The diffuser operates for 4 hours and then turns off automatically  
 8H - The diffuser operates for 8 hours and then turns off automatically



- "S" Button to control the spray intensity:  
After pressing the button, the indicator lights up, which determine the degree of spraying intensity.  
If all lights are on after a subsequent press, the intensity will return to level 1:

- : Level 1, spray 5 seconds, pause 180 seconds
- ● : Level 2, spray 10 seconds, pause 120 seconds
- ● ● : Level 3, spray 30 seconds, pause 90 seconds
- ● ● ● : Level 4, spray 60 seconds, pause 60 seconds
- ● ● ● ● : Level 5, spray 60 seconds, pause 30 seconds

4. Left and right atomizer control button:  
In the default setting, the left indicator lights up to start the left spray, after pressing the button once, the right indicator lights up to start the right spray.
5. Ambient light control button:  
In the default setting, the indicator is off.  
One button press sets the "Night Gloom" mode, two button presses set the "Warm (Yellow) Light Diffusion" mode; three button presses turn the light off.  
You can repeat the above operations by pressing the button again.

## Charging method:

1. Insert the charging cable into the Type-C port of the diffuser.
2. Insert the USB end of the charging cable into the USB port of the power adapter.  
(Note: Applies only to power adapters DC 5V/1A or DC 5V/2A with corresponding national standards.)
3. Charging status indicator (when turned on).
  - A.  
If the charging cable is not connected and the battery level is below 5%, the charging indicator is red and keeps flashing.
  - B.  
The charging indicator is red and keeps flashing.
  - C.  
When the battery is fully charged, the charge indicator will turn blue.

## Replacement of the built-in spray (atomization) core:

1. Remove the spray cap and unscrew the essential oil bottle.
2. Carefully pull out the atomizer core and essential oil suction tube.
3. Insert the oil suction tube into the new spray core, then insert the spray core and suction tube back into the hole.
4. Screw the oil bottle into the atomizer cover and align the cover of the atomizer and oil bottle into the corresponding position and insert them into the diffuser.

(Essential oils can be mildly irritating.

Be careful not to spill them.

In case of accidental contact, wash hands immediately.)



# SPECIFICATION

<b>PRODUCT NAME</b>	<b>Aroma diffuser with two jets</b>
<b>Model</b>	<b>DUAL STRONG</b>
<b>Optional power adapter</b>	<b>DC output voltage 5 V, 1 A / 5 V, 2 A</b>
<b>Dimensions</b>	<b>144mm*64mm*123mm (L*W*H)</b>
<b>Weight</b>	<b>Cca 670g</b>
<b>Battery capacity</b>	<b>4000 mAh</b>

Note:

All data are based on laboratory tests and may vary slightly depending on test conditions and environment.

# SAFETY INSTRUCTIONS

<b>DANGER</b>
<ul style="list-style-type: none"><li>• The essential oil is corrosive. Avoid direct contact of the essential oil with the skin, do not spray it in the eyes, mouth and nose.</li><li>• Never use a non-standard power adapter to charge the product.</li></ul>
<b>CAUTION</b>
<ul style="list-style-type: none"><li>• Do not disassemble or remove any components while the diffuser is in operation.</li><li>• Use at room temperature between 10 - 50 °C.</li><li>• It is recommended to use a pure plant-based essential oil, preferably less viscous.</li><li>• It is normal that sometimes the spray volume does not seem as intense when operating due to insufficient lighting or bad environment.</li></ul>

# WARRANTY

This product has been rigorously tested before leaving the manufacturer.

During the legal warranty period from the date of purchase, the customer may request a free repair or replacement due to defects caused by normal use.

If necessary, contact the seller of the product.

Failures resulting from accidents, improper use or maintenance are not covered by the warranty.

