

**ULTRASONICKÝ AROMA DIFUZÉR
BEWIT FAVORIT 300 WHITE
BEWIT FAVORIT 300 LIGHT WOOD
BEWIT FAVORIT 300 DARK WOOD**



Uživatelská příručka

Popis produktu

Aroma difuzér spojuje prvky tradiční orientální kultury s nejnovějšími poznatky a technologiemi moderní vědy. Pomocí ultrazvukové technologie rozkládá vodu a esenciální oleje na jemnou mlhu mikročástic, která se uvolňuje do vzduchu spolu s aktivními složkami a anionty. Tato technologie nezahřívá esenciální oleje, a proto zachovává jejich plné terapeutické účinky. Difuzér tak přirozeně provoní a zvlhčí prostředí, podporuje relaxaci, kvalitní spánek, koncentraci i celkovou pohodu a zároveň pomáhá neutralizovat nežádoucí pachy v interiéru.

Parametry a specifikace:

Materiál: PP (Favorite 300 White), ABS+PP (Favorite 300 Light Wood, Dark Wood)

Výkon: 8 W

Napětí: 24 V

Frekvence: 50–60 Hz

Input: AC 100 – 240V, 50/60 Hz

Output: DC 24V 600mA

Objem nádržky na vodu: 300 ml

Časovač: 10s/2H/4H/ON

Hluk: 20 ~ 40 dB

Počet výstupu vzduchu: 1

Rozměry: Ø 133 × 100 mm

Hmotnost difuzéru: 225 g


Délka kabelu: cca 150 cm

Rozsah: 10–30m²

Ultrazvuková

frekvence: 2.4 MHz

Obsah balení: difuzér, AC adaptér, návod



Varování

Před použitím tohoto přístroje si pozorně přečtěte následující bezpečnostní pokyny. Níže uvedená bezpečnostní opatření mají zabránit zranění vás i ostatních osob nebo zabránit poškození výrobku.

Bezpečnostní pokyny



NEBEZPEČÍ ÚRAZU ELEKTRICKÝM PROUDEM

- Zapojte přístroj pouze do síťové zásuvky instalované s předpisy, s napětím odpovídajícím jmenovitému napětí uvedenému na typovém štítku
- přístroj se v žádném případě nesmí namáčet do kapaliny. Přístroj nevystavujte vlhkosti ani jej nepoužívejte venku. Pokud přesto do přístroje vnikne kapalina, vytáhněte ihned zástrčku přístroje ze síťové zásuvky a nechte přístroj opravit kvalifikovaným odborným personálem.
- V případě provozních poruch a před čištěním přístroje vytahujte zástrčku ze síťové zásuvky.
- Pokud zástrčku vytahujete ze zásuvky, netahejte za kabel.
- Síťový přípojný kabel neomotávejte kolem přístroje a chraňte jej před poškozením.
- Pokud se napájecí kabel tohoto přístroje poškodí, musí jej vyměnit výrobce, jeho zákaznický servis nebo odborně kvalifikovaná osoba, aby se tak zabránilo nebezpečím
- Síťový přípojný kabel nepřehýbejte ani nestlačujte a pokládejte jej tak, aby na něj nikdo nemohl stoupnout ani o něj klopýtnout.
- přístroje, síťového kabelu ani zástrčky se nikdy nedotýkejte vlhkýma rukama.
- Ihned po použití odpojte přístroj od elektrické sítě. Pouze tehdy, je-li síťová zástrčka vytažená ze síťové zásuvky, je přístroj plně odpojen od proudu
- Plášť přístroje nesmíte opravovat. V takovém případě není zaručená bezpečnost a zaniká záruka. vadný přístroj nechte opravit pouze autorizovaným odborným personálem.
- Dbejte na to, aby za provozu nebyl síťový kabel mokrá ani vlhký.



- Přístroj nikdy nepoužívejte v blízkosti vody, zvláště ne v blízkosti umyvadel, van a podobných nádob. Blízkost vody představuje nebezpečí, i když je přístroj vypnutý



UPOZORNĚNÍ! Pokud tento bezpečnostní pokyn nedodržíte, dojde k nehodě. V důsledku může dojít k drobnému nebo těžkému ublížení na zdraví.

Výrobce neodpovídá za škody způsobené nesprávným používáním výrobku.

- Tento spotřebič není určen pro používání osobami (včetně dětí) se sníženými fyzickými, smyslovými nebo mentálními schopnostmi či nedostatkem zkušeností a znalostí, pokud nejsou trvale pod dozorem nebo pokud nebyly poučeny ohledně používání spotřebiče osobou zodpovědnou za jejich bezpečnost.
- Použití v prostředí s teplotou mezi 10 °C a 30 °C
- Zařízení se smí používat pouze s dodaným napájecím zdrojem.
- Přístroj nerozebírejte, nepravujte, nezahřívejte. Napájecí kabel nepřerušujte, nepoškozujte, nepravujte a nezatěžujte jej. Mohlo by dojít k úrazu elektrickým proudem nebo požáru.
- Používejte pouze **čistou studenou vodu** (balenou nebo z kohoutku).

- Nikdy **nepřekračujte maximální hladinu vody**. Vodu vždy nalijte před přidáním esenciálních olejů. K doplnění použijte odměrku nebo jinou nádobu – nenaplňujte nádržku přímo z kohoutku.
- Do nádržky vkládejte pouze **vodu s esenciálním olejem**. Jakékoli jiné kapaliny mohou zařízení trvale poškodit nebo být škodlivé při vdechování.
- Pokud se z přístroje kouří, je cítit podivný zápach nebo se vyskytne jakákoli neobvyklá situace, okamžitě jej přestaňte používat.
- Nedotýkejte se žádné části přístroje mokřýma rukama.
- Nenechávejte mlhu stříkat přímo na nábytek, oblečení nebo stěny.
- Esenciální olej může způsobit barvení. **Doporučujeme používat pouze esenciální oleje společnosti Bewit**. V případě náhodného potřísnění použijte čistý hadřík. **Vnitřní užití tohoto esenciálního oleje je zakázáno!**
- Pokud přístroj nepoužíváte, odpojte jej ze zásuvky.
- Při provozu přístroj ničím nezakrývejte.

Pokyny k použití

1. Používejte v prostředí s teplotou mezi 10 a 30 °C. Přístroj neumísťujte na přímé sluneční světlo, na mokřý povrch nebo na prašné místo.
2. Umístěte difuzér na rovný, stabilní povrch, mimo okraj stolu nebo nábytku. Pokud je uvnitř voda, přístroj nenaklánějte.
3. Opatrně sejměte vnější kryt směrem nahoru (FIG 1).
4. Zasuňte DC konektor do vstupu DC-IN na spodní straně zařízení. Napájecí kabel zajistěte v k tomu určeném otvoru (FIG 2).
5. Pomocí odměrky (není součástí balení) naplňte zásobník čistou studenou vodou (balenou vodou nebo vodou z vodovodu): nepřekračujte maximální hladinu vody (FIG 3). Zamezte rozlití vody mimo nádržku.
6. Do nádržky s vodou přidejte několik kapek esenciálního oleje podle požadované intenzity (FIG 3).
7. Nasadte kryt difuzéru tak, aby správně dosedl a nevznikly mezery (FIG 4) a zapojte adaptér do elektrické zásuvky.
8. Difuzér během provozu nenaklánějte.




FIG 1




FIG 2




FIG 3



FIG 4

Spuštění difuzéru:

- Stisknutí tlačítka **Power/Timer** – spustí se mlžení a rozsvítí se kontrolka **MID CONT** (nepřetržité foukání a LED podsvícení).

- Druhé stisknutí – rozsvítí se kontrolka **10s ON/OFF** (10 s v provozu /10 s pauza).
- Třetí stisknutí – rozsvítí se kontrolka **2H** (nastaví se funkce provozu s načasováním na 2 hodiny)
- Čtvrté stisknutí – rozsvítí se kontrolka **4H** (nastaví se funkce provozu s načasováním na 4 hodiny)
- Páté stisknutí – přístroj se vypne.


Pro úplné vypnutí podržte tlačítko déle než 2 sekundy.

Režim svícení – Tlačítko LIGHT (SVĚTLO)

- **Zapnutí světla:** Pro aktivaci LED osvětlení stiskněte tlačítko **LIGHT**. Barvy se budou měnit automaticky.
- **Výběr barvy:** Dalším stiskem tlačítka **LIGHT** můžete zafixovat vybranou barvu.
- **Vypnutí světla:** Podržte tlačítko **LIGHT** po dobu 2 sekund pro úplné vypnutí osvětlení.

Difuzér je vybaven 7barevným LED osvětlením. Opakovaným stiskem tlačítka **LIGHT** můžete měnit:

- **Režim barvy:** stálá barva → měnící se barva → vypnutí světla
- **Intenzitu světla:** 100 % → 50 % → vypnutí osvětlení



Údržba

- Doporúčujeme vám po každém použití zcela vylít vodu a otřít jednotku měkkým hadříkem. Pokud jednotku delší dobu nepoužíváte, ujistěte se, že jste z nádrčky zcela vylili zbývající vodu a uložte ji na suchém místě.
- Před použitím nového typu esenciálního oleje nebo domácí vůně vyčistěte jednotku podle pokynů k údržbě.
- Vyčistěte nádrčku na vodu alespoň každý týden a nejlépe po 5-6 použití. K čištění zařízení nepoužívejte chemické přípravky (jako jsou kyseliny...atd.) ani korozivní čisticí prostředky.
- Nikdy neponořujte zařízení do vody.
- Nedovolte, aby se kovové předměty nebo ostré předměty (jako špendlík, klíč) dostaly do kontaktu s ultrazvukovou mlžnou deskou.



Likvidace po skončení životnosti přístroje

Tento výrobek nesmí být likvidován jako běžný komunální odpad. Po skončení životnosti jej odevzdejte do sběrného dvora nebo do místa určeného k recyklaci elektrických a elektronických zařízení, v souladu s platnými právními předpisy. Správná likvidace pomáhá chránit životní prostředí a zdraví lidí.

Obaly výrobku (papír, plast) likvidujte v souladu s místními předpisy pro třídění odpadu.

Řešení problémů

Problém	Možná příčina	Řešení
Difuzér se nezapíná	Není připojen k napájení / vadný adaptér	Zkontrolujte připojení adaptéru, případně vyzkoušejte jinou zásuvku
Nevychází mlha	Nedostatek vody / překročená max. hladina / kryt není správně nasazen	Doplňte vodu, nasadte kryt správně
Slabá mlha	Znečištěná ultrazvuková destička / tvrdá voda	Vyčistěte destičku jemným hadříkem, použijte čistou vodu
Přístroj vydává neobvyklý zvuk	Nedostatek vody / nerovný povrch	Doplňte vodu, umístěte na rovný povrch
Světlo nesvíí	LED je vypnutá	Stiskněte tlačítko LIGHT
Nepříjemný zápach	Nádržka není vyčištěna	Vyčistěte nádržku měkkým hadříkem
Voda uniká z nádržky	Kryt není správně nasazen / přístroj je nakloněný	Nasadte kryt správně, postavte na vodorovný povrch

Záruka

Tento výrobek byl před opuštěním výrobce přísně testován. Během zákonné záruční doby od data zakoupení může zákazník požádat o bezplatnou opravu nebo výměnu z důvodu poruch vzniklých běžným používáním. V případě potřeby se obraťte na prodejce výrobku.

Na poruchy vzniklé v důsledku nehod, nesprávného používání nebo údržby se záruka nevztahuje.



BEWIT Natural Medicine, s.r.o.
Michalská 2030,
710 00 Ostrava
Tel.: (+420) 731 739 539
Email: info@bewit.cz



ES Prohlášení o shodě

podle zákona č. 22/1997 Sb., § 13 ve znění zákona č. 71/2000 Sb., zákona č. 102/2001 Sb., zákona č. 205/2002 Sb., zákona č. 226/2003 Sb. a zákona č. 277/2003 Sb.

Výrobce:

BEWIT Natural Medicine, s.r.o.

Michalská 2030

710 00 Ostrava

IČ: 29443237

Osoba pověřená kompletací technické dokumentace:

BEWIT Natural Medicine, s.r.o.

Michalská 2030

710 00 Ostrava

IČ: 29443237

prohlašuje výhradně na vlastní odpovědnost, že níže uvedené zařízení odpovídá základním požadavkům: **zákon č. 22/1997 Sb.** o technických požadavcích na výrobky, **NV. 176/2008 Sb.** o technických požadavcích na strojní zařízení, **zákon 90/2016 Sb.** o posuzování shody stanovených výrobků při jejich dodávání na trh, **NV č. 118/2016** požadavky vychází ze směrnice 2014/35/EU/LVD, kterým se stanoví technické požadavky na elektrická zařízení nízkého napětí, **NV č. 117/2016 Sb.** požadavky vychází ze směrnice 2014/30/EU EMC, kterým se stanoví technické požadavky na výrobky z hlediska jejich elektromagnetické kompatibility. **Zákon č. 634 /1992 Sb.** o ochraně spotřebitele, **zákon č. 387/2024 Sb.** o obecné bezpečnosti výrobku, **zákon č. 258/2000 Sb.** o ochraně veřejného zdraví, **vyhláška č. 38/2001 Sb.** Ministerstva zdravotnictví o hygienických požadavcích na výrobky určené pro styk s potravinami a pokrmy, a příslušným předpisům a normám, které z těchto nařízení vyplývají.

Elektrické zařízení:

Název:	Aroma difuzér
Typ:	Favorit 300
Výrobní číslo:	-
Rok výroby:	2025

Popis a určení elektrického zařízení:

Ultrazvukový aroma difuzér.



**NATURAL
MEDICINE**

BEWIT Natural Medicine, s.r.o.

Michalska 2030, 710 00 Ostrava

Česká Republika

IČ: 29443237 DIČ: CZ29443 237

+420 732 790 599

info@bewit.love

www.bewit.love

Seznam použitých technických předpisů a norem:

EN IEC 55014-1, EN IEC 55014-1:2021, EN IEC 55014-2:2021, IEC 62321-3-1:2013, IEC 62321-4:2013+AMD1:2017,

IEC 62321-5:2013, IEC 62321-6:2015, IEC 62321-7-1:2015 & IEC 62321-7-2:2017, IEC 62321-8:2017


Zvolený postup posuzování shody:

Posouzení shody za stanovených podmínek dovozcem: č. 22/1997 Sb., ve znění změn, § 12, odst. 3, písm. a).

Elektrické zařízení splňuje všechna příslušná ustanovení těchto právních předpisů Evropských společenství: Směrnice Evropského parlamentu a Rady 2006/42/ES O STROJNÍCH ZAŘÍZENÍCH (NV 176/2008 Sb.)

V Ostravě dne 10.9.2025

Jméno a příjmení / funkce ve společnosti : Ing. Jiří Černota, jednatel

Podpis: 



**NATURAL
MEDICINE**

BEWIT Natural Medicine, s.r.o.

Michalská 2030, 710 00 Ostrava

Česká Republika

IČ: 29443237 DIČ: CZ29443 237

+420 732 790 599

info@bewit.love

www.bewit.love

EN

**ULTRASONIC AROMA DIFFUSER
BEWIT FAVORIT 300 WHITE,
BEWIT FAVORIT 300 LIGHT DARK
BEWIT FAVOURITE 300 DARK
WOOD**



User Manual

Product Description

The aroma diffuser combines elements of traditional oriental culture with the latest knowledge and technology of modern science. Using ultrasonic technology, it breaks down water and essential oils into a fine mist of microparticles that is released into the air along with active ingredients and anions. This technology does not heat the essential oils and therefore preserves their full therapeutic effects. The diffuser thus naturally scents and humidifies the environment, promotes relaxation, quality sleep, concentration and overall well-being, while helping to neutralize unwanted odors in the interior

Specifications:

Material: PP(Favorite White), ABS+PP (Favorite 300 Light Wood, Dark Wood)

Power: 8 W

Voltage: 24 V

Frequency: 50–60 Hz

Input: AC 100 – 240V, 50/60 Hz

Output: DC 24V 600mA

Water tank capacity: 300 ml

Timer Options: 10s/2H/4H/ON

Noise: 20 ~ 40 dB

Number of air outlets: 1

Dimensions: Ø 133 × 100 mm


Diffuser weight: Approx. 225 g

Cord Length: Approx. 150 cm

Ultrasonic Frequency: 2.4 MHz

Applicable Room Size: 10 – 30 m²

Contents of the package: Difuser, AC Adapter, Instructiona Manual



Please read the following safety instructions carefully before using this device. The following safety precautions are intended to prevent injury to you and others or to prevent damage to the product.

Safety Instructions



RISK OF ELECTRIC SHOCK

- Plug the device only into a properly installed mains socket with a voltage corresponding to the rated value on the type plate
- Never immerse the device in liquid. Do not expose the device to moisture or use it outdoors. If liquid still enters the device, immediately unplug the device from the power outlet and have the device repaired by qualified professional personnel.
- In the event of operational faults and before cleaning the appliance, remove the plug from the mains socket.
- When pulling the plug out of the socket, do not pull the cable.
- Do not wrap the power cord around the device and protect it from damage.
- If the power cord of this device becomes damaged, it must be replaced by the manufacturer, its customer service or a qualified person to prevent hazards
- Do not bend or squeeze the mains cable and lay it so that no one can step on it or trip over it.
- Never touch the appliance, power cord or plug with wet hands.
- Disconnect the appliance from the mains immediately after use. The device is completely disconnected from the power supply only when the mains plug is removed from the socket
- You must not repair the instrument casing. In this case, safety is not guaranteed, and the warranty is void.
- Make sure that the mains cable is not wet or damp during operation.



- Never use the device near water, especially not near sinks, bathtubs and similar containers. The proximity of water poses a hazard even when the device is switched off



WARNING! Failure to observe this safety instruction could result in an accident. As a result, minor or serious bodily injury may occur.

The manufacturer is not liable for damages caused by improper use of the product.

- This appliance is not intended for use by persons (including children) with impaired physical, sensory or mental abilities or lack of experience and knowledge, unless they are permanently supervised or have been instructed in the use of the appliance by a person responsible for their safety.
- Use in environments with temperatures between 10 °C and 30 °C
- The device must only be used with the supplied power supply.
- Do not disassemble, modify or heat the device. Do not cut, damage, modify or strain the power cord. Electric shock or fire could result.
- Use only **clean, cold water** (bottled or tap).

- **Never exceed the maximum water level.** Always pour the water before adding the essential oils. Use a measuring cup or other container to refill - do not fill the reservoir directly from the tap.
- Only add **water with essential oil** to the reservoir. Any other liquids may permanently damage the equipment or be harmful if inhaled.
- If the appliance smokes, has a strange smell or any unusual situation occurs, stop using it immediately.
- Do not touch any part of the device with wet hands.
- Do not let the mist spray directly onto furniture, clothes or walls.
- Essential oil can cause staining. **We recommend using only Bewit essential oils.** In case of accidental spillage, use a clean cloth. **Internal use of this essential oil is prohibited!**
- Unplug the appliance when not in use.
- Do not cover the device with anything during operation.

Instructions for Use

1. Use in an environment with a temperature between 10 and 30 °C. Do not place the device in direct sunlight, on a wet surface or in a dusty place.
2. Place the diffuser on a flat, stable surface, away from the edge of a table or furniture. If there is water inside, do not tilt the device.
3. Carefully remove the outer cover upwards (FIG 1).
4. Insert the DC connector into the DC-IN input on the bottom of the device. Secure the power cable in the designated hole (FIG 2).
5. Using a measuring cup (not included), fill the reservoir with clean cold water (bottled or tap water): do not exceed the maximum water level (FIG 3). Avoid spilling water outside the tank.
6. Add a few drops of essential oil to the water reservoir according to the desired intensity (FIG 3).
7. Replace the diffuser cover so that it fits properly and no gaps are created (FIG 4) and plug the adapter into an electrical outlet.
8. Do not tilt the diffuser during operation.




FIG 1




FIG 2




FIG 3



FIG 4

Starting the Diffuser:

- Pressing the **Power/Timer** button - the misting starts and the **MID CONT** light (continuous blowing and LED backlight) lights up.
- Second press - the **10-second ON/OFF cycle** indicator lights up (10 seconds in operation / 10 seconds pause).

- Third press - the **2H** light comes on (sets the operation function with timing for 2 hours)
- Fourth press - the **4H** light comes on (sets the operation function with 4 hours timing)
- Fifth press - the device switches off.


To switch off completely, hold the button for more than 2 seconds.

Light mode - LIGHT button

- **Turning on the light:** Press the **LIGHT** button to activate the LED lighting. The colours will change automatically.
- **Choice of colour:** Press the **LIGHT** button again to fix the selected colour.
- **Lights out:** Hold the **LIGHT** button for 2 seconds to turn off the lights completely.

The diffuser is equipped with 7-colour LED lighting. Press the **LIGHT** button repeatedly to change:

- **Color mode:** steady color → changing color → light off
- **Light intensity:** 100 % → 50 % → switch off lighting



Maintenance

- We recommend emptying the water tank completely after each use and wipe the device with a soft cloth. If you do not use the device for a long period of time, make sure you have completely drained the remaining water from the tank and store it in a dry place.
- Before using a new type of essential oil or home fragrance, clean the device according to the maintenance instructions.
- Clean the water tank at least every week and preferably after 5-6 uses. Do not use chemical products (such as acids...etc.) or corrosive cleaning agents to clean the equipment.
- Never immerse the device in water.
- Do not allow metal objects or sharp objects (such as a pin, key) to come into contact with the ultrasonic misting plate.



Disposal at the end of the life of the device

This product must not be disposed of as normal municipal waste. At the end of its useful life, take it to a collection yard or an electrical and electronic equipment recycling site, in accordance with applicable legislation. Proper disposal helps protect the environment and human health. Dispose of product packaging (paper, plastic) in accordance with local waste separation regulations.

Troubleshooting

The problem	Possible cause	Solution
The diffuser does not switch on	Not connected to power / faulty adapter	Check the adapter connection, or try another socket
The fog is not coming out	Lack of water / max. level exceeded / cover not fitted correctly	Refill water, fit the cover correctly
Faint fog	Contaminated ultrasonic plate / hard water	Clean the plate with a soft cloth, use clean water
The device makes an unusual sound	Lack of water / uneven surface	Refill with water, place on a flat surface
The light does not shine	LED is off	Press the LIGHT button
Unpleasant smell	The reservoir is not cleaned	Clean the reservoir with a soft cloth
Water leaking from the tank	The cover is not correctly fitted / the device is tilted	Put the cover on correctly, stand on a horizontal surface

Warranty

This product has been rigorously tested before leaving the manufacturer. During the legal warranty period from the date of purchase, the customer may request a free repair or replacement due to defects caused by normal use. If necessary, contact the seller of the product.

Failures resulting from accidents, improper use or maintenance are not covered by the warranty.



BEWIT Natural Medicine, s.r.o.
Michalská 2030,
710 00 Ostrava
Tel: (+420) 731 739 539
Email: info@bewit.cz

**EU Declaration of Conformity**

according to Act No. 22/1997 Coll., as amended by Act No. 71/2000 Coll., Act No. 102/2001 Coll., Act No. 205/2002 Coll., Act No. 226/2003 Coll. and Act No. 277/2003 Coll.

Manufacturer:

BEWIT Natural Medicine, s.r.o.
Michalská 2030
710 00 Ostrava
Company ID: 29443237

Person authorized to compile technical documentation:

BEWIT Natural Medicine, s.r.o.
Michalská 2030
710 00 Ostrava
Company ID: 29443237

We hereby declare, under our sole responsibility, that the equipment specified below complies with the essential requirements of:

Act No. 22/1997 Coll. on Technical Requirements for Products,
Government Regulation No. 176/2008 Coll. on Technical Requirements for Machinery,
Government Regulation No. 90/2016 Coll. on the Assessment of Conformity of Specified Products when Placed on the Market,
Government Regulation No. 118/2016 Coll. laying down technical requirements in accordance with Directive 2014/35/EU (LVD – Low Voltage Directive),
Government Regulation No. 117/2016 Coll. laying down technical requirements in accordance with Directive 2014/30/EU (EMC – Electromagnetic Compatibility Directive),
Act No. 634/1992 Coll. on Consumer Protection,
Government Regulation No. 387/2002 Coll. on General Product Safety,
Government Regulation No. 258/2000 Coll. on Public Health Protection,
Vyhláška No. 38/2001 Coll. of the Ministry of Health on hygienic requirements for products intended to come into contact with foodstuffs,
and other related regulations and standards that apply to the product.

Electrical equipment:

Name	Aroma diffuser
Type/Model	FAVORIT 300
Year of manufacture	2025

Description and purpose of the electrical equipment:

Ultrasonic aroma diffuser.



NATURAL
MEDICINE

BEWIT Natural Medicine, s.r.o.

Michalská 2030, 710 00 Ostrava
Česká Republika
IČ: 29443237 DIČ: CZ29443 237

+420 732 790 599
info@bewit.love
www.bewit.love

List of applied technical regulations and standards:

EN IEC 55014-1, EN IEC 55014-1:2021, EN IEC 55014-2:2021, IEC 62321-3-1:2013,
IEC 62321-4:2013+Amd01:2017, IEC 62321-5:2013, IEC 62321-6:2015,
IEC 62321-7-1:2015 & IEC 62321-7-2:2017, IEC 62321-8:2017

Chosen conformity assessment procedure:

Assessment of conformity under the conditions specified by importer: Act No. 22/1997 Coll., as amended, § 12, paragraph 3, letter a).

The electrical equipment complies with all relevant provisions of the following legal regulations of the European Community:

Directive 2006/42/EC of the European Parliament and of the Council on machinery (Government Regulation No. 176/2008 Coll.).

In Ostrava, date September 10th 2025

First name and surname, position in the company:

Jiri Cernota, founder and managing director

Signature:



**NATURAL
MEDICINE**

BEWIT Natural Medicine, s.r.o.

Michalská 2030, 710 00 Ostrava

Česká Republika

IČ: 29443237 DIČ: CZ29443 237

+420 732 790 599

info@bewit.love

www.bewit.love