

GLASS AROMA DIFFUSER 3D BALL LUX



User Manual

Product Description

The aroma diffuser combines elements of traditional oriental culture with the latest knowledge and technologies of modern science. Using ultrasonic technology, it breaks down water and essential oils into a fine mist of micro-particles, which is released into the air along with active ingredients and anions. This technology does not heat the essential oils, thus preserving their full therapeutic effects. The diffuser naturally fragrances and humidifies the environment, promotes relaxation, quality sleep, concentration, and overall well-being, while also helping to neutralise unwanted odours indoors.

Specifications

Product: Glass Aroma Diffuser 3D BALL LUX

Dimensions: 150 x 230 mm

Timer: ON / 15 s (intermittent misting) / 1 h / 3 h

Backlight: 7 LED colours

Output: DC 24 V



Weight: 790 g

Range: up to 30 m²

Tank volume: 160 ml

Material: plastic body (ABS + PP), glass cover

Accessories: AC power adapter, measuring cup, instruction manual



① Position of the DC power input port

② Air inlet


③ Glass cover

④ Inner cover

⑤ Air outlets

⑥ Water tank

⑦ Function button / status indicator



Warning

Please read the following safety instructions carefully before using this appliance. The safety precautions below are intended to prevent injury to yourself and others or prevent damage to the product.

Safety instructions



DANGER OF ELECTRIC SHOCK

- Only plug the appliance into a mains socket installed in accordance with regulations, with a voltage corresponding to the rated voltage stated on the type plate.
- Under no circumstances must the appliance be immersed in liquid. Do not expose the appliance to moisture or use it outdoors. If liquid does get into the appliance, immediately unplug the appliance from the mains socket and have the appliance repaired by qualified specialist personnel.
- In the event of operating faults and before cleaning the appliance, unplug it from the mains socket.
- When pulling the plug out of the socket, do not pull the cable.
- Do not wrap the mains connecting cable around the appliance and protect it from damage.
- If the power cable of this appliance becomes damaged, it must be replaced by the manufacturer, its customer service, or a professionally qualified person to prevent hazards.
- Do not bend or compress the mains connecting cable and lay it in such a way that no one can step on it or trip over it.
- Never touch the appliance, mains cable, or plug with wet hands.
- Disconnect the appliance from the mains immediately after use. The appliance is completely disconnected from the power supply only when the mains plug has been removed from the socket. Do not attempt to repair the appliance casing. In such cases, safety cannot be guaranteed and the warranty will be void. Any faulty appliance must be repaired only by authorised qualified personnel.
- Ensure that the mains cable is not wet or damp during operation.



- Never use the appliance near water, especially not near washbasins, bathtubs, and similar containers. Proximity to water poses a danger, even when the appliance is switched off.



WARNING! Failure to observe this safety instruction will result in an accident. This may lead to minor or severe personal injury.


The manufacturer is not liable for damages caused by improper use of the product.

- This appliance is not intended for use by persons (including children) with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they are constantly supervised or have been instructed regarding the use of the appliance by a person responsible for their safety.
- Do not use this product at temperatures higher than 50 °C or lower than 10 °C.
- After installing and operating the diffuser, you must not handle it in such a way that it overturns or tilts. Otherwise, oil will spill out and the air pump will be damaged, causing permanent damage to the product.
- Do not touch any part of the appliance with wet hands.
- Please switch off the main power when changing the oil.
- Modification or disassembly of this product is not permitted. Violation will void the warranty and may cause damage.


Operating instructions

Method of application:


1. Remove the glass cover and then the inner cover in the direction of the arrow. When removing the tank, a small amount of water from previous use may remain inside. Keep the tank in an upright position. Do not tilt it horizontally to prevent residual water from entering the internal parts of the appliance and causing a malfunction.



2. When filling the water tank, do not exceed the maximum limit. Add 2-3 drops of essential oil.




3. Install the decorative and inner cover in the direction of the arrow and ensure they are in place.



4. Insert the output plug of the power adapter into the DC power input port and connect the power supply. Gently press the MIST button to select the desired speed. The corresponding indicator light will turn on and the device will begin operating. Make sure the product is placed on a flat, stable surface during use.

Note: If the water temperature or quality is affected by external factors, the amount of mist produced may be lower at the beginning of operation. However, after a few minutes, the mist output will return to normal and stabilise.

Button functions:



LIGHT

- Press the button once – switch on RGB lighting (automatic colour change).
- Press the button twice – stop on the current colour.
- Press the button three times – change colour.
- Press the button four times – next colour change.
- Repeatedly pressing – cycles through colours.
- Long press of the button – turns off the light.


MIST

- Press the button once – continuous mist (until water runs out).
- Press the button twice – intermittent mist (15 seconds on / 15 seconds off).
- Press the button three times – timer setting for 1 hour.
- Press the button four times – timer setting for 3 hours.
- Press the button five times – switch off the device.
- Long press of the button (2 beeps) – dense mist.
- Long press of the button (1× beep) – fine mist.

Cleaning Method

- Unplug the power adapter from both the socket and the device. Then remove the outer glass cover and the inner tank cover.
- Pour out any remaining water from the tank. Be careful not to let water get into the air outlet on the bottom of the tank.
- Dampen a cloth in warm water with a small amount of neutral detergent and wring it out thoroughly. Carefully wipe the device and the tank cover.
- Clean the bottom of the tank using cotton buds or a soft cloth. Do not touch the ultrasonic plate at the bottom of the tank and do not press on it to avoid damage.

Ultrasonic plate



Precautions for use:

- Clean the water tank regularly. If the bottom of the tank or the ultrasonic plate is dirty, the device may malfunction. We recommend cleaning approximately after every 6 uses (roughly every 5 – 7 days).
- Do not move or tilt the device during operation to prevent water from entering the internal parts.
- When refilling water, always open the inner tank cover. Never pour water through the mist outlet.
- Water droplets may form on the tank cover, internal parts of the device, or the glass cover. Exercise extra caution when opening the device.
- Always unplug the power adapter from the socket when the device is not in use.
- If the device is not used for a long time, dry it thoroughly and store it in a dry place.
- Only use natural essential oils derived from plants. Do not use perfumes or synthetic fragrances, as this could damage the device.
- When filling the tank to the maximum line, add 2–3 drops of essential oil. You can adjust the amount according to the water volume and desired fragrance intensity.
- Never add essential oil to an empty tank or a tank with very little water, to prevent damage to the device.

Emergency procedure for accidental water spillage:

- If water spills due to accidental knocking or tilting of the device, follow these steps to prevent damage:
 - Immediately unplug the power adaptor from both the socket and the device.
 - Remove the glass cover and the inner tank cover.
 - Pour out any remaining water from the tank.
 - Remove any accumulated water from the internal parts of the device and dry it thoroughly.
 - Before further use, allow the device to dry for at least 48 hours in a dry and well-ventilated place.



Disposal at the end of the device's life

This product must not be disposed of as ordinary household waste. At the end of its life, hand it over to a collection point or a designated place for the recycling of electrical and electronic equipment, in accordance with applicable legal regulations. Proper disposal helps protect the environment and the health of people.

Dispose of product packaging (paper, plastic) in accordance with local waste sorting regulations.

Troubleshooting

Problem	Possible cause	Solution
Diffuser does not switch on	Not connected to power / faulty adaptor	Check adaptor connection, or try a different socket
No mist is coming out	Lack of water / maximum level exceeded / cover not fitted correctly	Top up with water, fit the cover correctly
Weak mist	Dirty ultrasonic plate / hard water	Clean the plate with a soft cloth, use clean water
The device is making an unusual sound	Lack of water / uneven surface	Top up with water, place on a flat surface
Light not working	LED is off	Press the LIGHT button
Unpleasant odour	Tank not cleaned	Clean the tank with a soft cloth
Water leaking from the tank	Cover not fitted correctly / device is tilted	Fit the cover correctly, place on a horizontal surface

Warranty

This product has been strictly tested before leaving the manufacturer. During the statutory warranty period from the date of purchase, the customer may request free repair or replacement due to faults arising from normal use. If necessary, please contact the product seller.

The warranty does not cover faults arising from accidents, improper use or maintenance.



BEWIT Natural Medicine, s.r.o.
Michalská 2030, 710 00 Ostrava
Czech Republic
Tel.: (+420) 552 305 105
Email: info@bewit.love

**EU Declaration of Conformity**

according to Act No. 22/1997 Coll., as amended by Act No. 71/2000 Coll., Act No. 102/2001 Coll., Act No. 205/2002 Coll., Act No. 226/2003 Coll. and Act No. 277/2003 Coll.

Manufacturer:

BEWIT Natural Medicine, s.r.o.
Michalská 2030
710 00 Ostrava
Company ID: 29443237

Person authorized to compile technical documentation:

BEWIT Natural Medicine, s.r.o.
Michalská 2030
710 00 Ostrava
Company ID: 29443237

We hereby declare, under our sole responsibility, that the equipment specified below complies with the essential requirements of:

Act No. 22/1997 Coll. on Technical Requirements for Products,
Government Regulation No. 176/2008 Coll. on Technical Requirements for Machinery,
Government Regulation No. 90/2016 Coll. on the Assessment of Conformity of Specified Products when Placed on the Market,
Government Regulation No. 118/2016 Coll. laying down technical requirements in accordance with Directive 2014/35/EU (LVD – Low Voltage Directive),
Government Regulation No. 117/2016 Coll. laying down technical requirements in accordance with Directive 2014/30/EU (EMC – Electromagnetic Compatibility Directive),
Act No. 634/1992 Coll. on Consumer Protection,
Government Regulation No. 387/2002 Coll. on General Product Safety,
Government Regulation No. 258/2000 Coll. on Public Health Protection,
Vyhláška No. 38/2001 Coll. of the Ministry of Health on hygienic requirements for products intended to come into contact with foodstuffs,
and other related regulations and standards that apply to the product.

Electrical equipment:

Name	Aroma diffuser
Type/Model	3D BALL LUX
Year of manufacture	2026

Description and purpose of the electrical equipment:

Ultrasonic aroma diffuser.



NATURAL
MEDICINE

BEWIT Natural Medicine, s.r.o.
Michalská 2030, 710 00 Ostrava
Číslo registrace: 29443237
IČ: 29443237 | DIČ: CZ29443237

+420 732 730 599
info@bewit.cz
www.bewit.cz

List of applied technical regulations and standards:

EN IEC 55014-1, EN IEC 55014-1:2021, EN IEC 55014-2:2021, IEC 62321-3-1:2013,
IEC 62321-4:2013+Amd01:2017, IEC 62321-5:2013, IEC 62321-6:2015,
IEC 62321-7-1:2015 & IEC 62321-7-2:2017, IEC 62321-8:2017

Chosen conformity assessment procedure:

Assessment of conformity under the conditions specified by importer: Act No. 22/1997 Coll.,
as amended, § 12, paragraph 3, letter a).

The electrical equipment complies with all relevant provisions of the following legal
regulations of the European Community:

Directive 2006/42/EC of the European Parliament and of the Council on machinery
(Government Regulation No. 176/2008 Coll.).

In Ostrava, date *11/2/2026*

First name and surname, position in the company:

Jiri Cernota, founder and managing director

Signature: *Jiri Cernota*



NATURAL
MEDICINE

BWIT Natural Medicine, s.r.o.
Družstevní 2270, 717 01 Ostrava
IČO: 29442227, DIČ: CZ29442227
Kontakt: +420 58 561 780 410
info@bwit.cz
www.bwit.cz